



I1076

FILL-END = MAX 10,00 X 1,00 (0.394" X 0.039")
 DRIVER = OKI MSM58292, HD61603

SEG.	4B	4A	4F	3G	3B	3A	3F	COL	2G	2B	2A	2F	1G	1B	1A	1F	-	:	▲
PIN#	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38
SEG.	BP	B	1E	1D	1C	DP1	2E	2D	2C	DP2	3E	3D	3C	DP3	4E	4D	4C	4G	NC
PIN#	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19