



FILL-END = MAX 10,00 X 1,00 (0.394" X 0.039")  
 DRIVER = OKI MSM58292, HD61603

I1118

SEG.	6B	6A	6F	6G	5B	5A	5F	5G	COL2	NC	4B	NC	NC	NC	4A	4F	4G	NC	NC	3B	NC	NC	3A	3F	3G	COL1	2B	2A	2F	2G	1B	1A	1F	1G	BP
PIN#	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70
SEG.	BP	1E	1D	1C	DP1	2E	2D	2C	DP2	3E	3D	NC	NC	NC	NC	3C	NC	DP3	4E	4D	NC	NC	NC	4C	NC	DP4	5E	5D	NC	NC	5C	DP5	6E	6D	6C
PIN#	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35